

Inhaltsverzeichnis

Grid - View 3 3

Grid - View 3

The Grid view can be called directly with the **3** key. This view is also called Multi-EPG.

In this view, the EPG is displayed graphically and is intended to provide an overview of which shows are running now and will be broadcast on the various stations.


Current or planned recordings are displayed above the event using a red bar. The bar also shows the pre and post padding. A key can be set in the setup menu item „[Key for the Grid](#)“. By default, channels that were selected in the setup menu item „Select bouquet“ for scanning or to be displayed are available.

The screenshot displays the SmartEPGvu+ Grid View 3 interface. At the top, it shows the channel '52. DW English HD' and a timeline from 14:00 to 17:00. The main grid lists various programs across different channels. A red bar highlights the current program 'DW News' at 14:00. The interface includes a top bar with the channel '52. DW English HD' and a bottom bar with navigation controls and the 'SmartEPGvu+' logo.

Channel	14:00	15:00	16:00	17:00
52. DW English HD	Auf legendären Routen USA - Auf den Spuren von Jack Kerouac	Aufgedeckt - Rätsel der Geschichte Die Frau Jesu	Moderne Wunder Top 10 - Essen	Quizjagd
CNN	CNN TALK			
UHD1	Free Fenster			
Magazin	Matchball Becker	Handball Europameisterschaft in Ungarn	Handball Europameisterschaft in Ungarn und der Slowakei	Ski Alpin FIS Weltcup
UHD	Derzeit keine UHD-Sendung im Programm			
Bild	Mayday - Wundersame Retter	Mayday - Spektakuläre Landungen	Mayday - Fußballteam Chanc	Mayday - Voll erwischt
Kika	Die F	Schloss Einstein	Club der mag	Club der mag
DW	DW News	DW News Asia	Special Interview	DW News

Navigation controls at the bottom include: Set timer, New search, Go to event in guide, AUDIO, Go to fileDB, Change page, +/- 24h, Prime time, Current program, Switch to channel, Switch bouquet, EPG, Info, Guide, Overview, Soon, Timer, Search list, MENU, Menu, EXIT, Exit.

There is another grid layout with an info column on the right. The configuration is done via the [Grid Layout](#) - or via the web interface.



Explanation of the keys

	Program a timer or edit an existing timer
	Create and display a search from the selected event. This feature can also be used to quickly search for replays
	Jumps to the program in the Guide - View 1
	Switch to the File Database Editor
	Scroll backwards by page
	Scroll forward page by page
	Jumps back 24 hours from the marked event
	Jumps forward 24 hours from the marked event
	Jump to Prime time
	Jumps to the current broadcast
	Switches to the selected channel
	OK - Long => Opens a window to select another bouquet
	Display the extended information of the selected program
	Jump to View 1 - Guide
	Jump to View 2 - Overview
	Jump to View 4 - Next event
	Jump to View 5 - Timer
	Jump to View 6 - Search
	Calls up the SmartEPGvu+ menu
	Exit



If the „Set timer“ key, i.e. the record key, is pressed, the display of the first line in the individual key actions menu changes as follows:



Program a timer or edit an existing timer



Block or unblock timers



Change timer type (R, P or M timer) - more detailed explanation under Timer types



Delete the marked timer



Create and display a search from the selected event. This feature can also be used to quickly search for replays



Jumps to the program in the Guide - View 1



Switch to the File Database Editor

From:

<https://nayal.de/> -

Permanent link:

<https://nayal.de/doku.php/en:sicht3>

Last update: **2024/01/14 19:39**

