

Inhaltsverzeichnis

Next event - View 4 3

Next event - View 4

This view can be assigned to any key or called directly with the **4** key.

This view shows the programs that are about to start, sorted by start time. This allows you to see which programs are about to start on the other channels.

A key to call up this view can be set in the setup menu item „ [Key for the Next event View](#)“.

The screenshot displays the 'Next event - View 4' interface. At the top, it shows '3. hr-fernsehen HD' and 'Tue 25.01'. The main list shows programs starting 'Soon' (around 14:30). The selected program is 'Herzdamen an der Elbe' (CINEMA) starting at 14:30. A detailed view of this program is shown on the right, including a description: 'Fernsehfilm Deutschland 2013. Tue 25.01. 14:30 - 16:00. 90 min. Wer in Dresden nach österreichischer Küche sucht, der geht ins Restaurant "Lieblich an der Elbe" im idyllischen Elbschlösschen, das Maria Lieblich gemeinsam mit ihren Freundinnen Steffi Krieg und Carola Bleibtreu erfolgreich etabliert hat. Doch die Bank sitzt den ambitionierten Gastronominnen mit hohen Kreditforderungen im Nacken. Als ihnen der elegante Reeder Hermann Augartner einen lukrativen Catering-Job offeriert, sehen die Damen ihre große Chance gekommen, sich aus der geschäftlichen Notlage zu befreien.'

At the bottom, there is a navigation bar with the following options: Set timer, New search, Go to event in guide, Switch filter (yellow key), Go to fileDB, Change page, Switch to channel, Switch bouquet, EPG Info, Guide, Overview, Grid, Timer, Search list, MENU Menu, EXIT Exit.

SmartEPGvu⁺

Explanation of the keys

The meaning of the yellow key **4** is explained in detail under [Select genre icon](#)

	Program a timer or edit an existing timer
	Create and display a search from the selected event. This feature can also be used to quickly search for replays
	Jumps to the program in the Guide - View 1
	Toggle the display of Genre Filter groups: None/User defined/Entertainment/Information
	Switch to the File Database Editor
	Scroll backwards by page
	Scroll forward page by page
	Switches to the selected channel
	OK - Long => Opens a window to select another bouquet
	Display the extended information of the selected program
	Jump to View 1 - Guide
	Jump to View 2 - Overview
	Jump to View 3 - Grid
	Jump to View 5 - Timer
	Jump to View 6 - Search
	Calls up the SmartEPGvu+ menu
	Exit



If the „Set timer“ key, i.e. the record key, is pressed, the display of the first line in the legend changes as follows:

	Program a timer or edit an existing timer
	Block or unblock timers
	Change timer type (R, P or M timer) - more detailed explanation under Timer types
	Delete the marked timer
	Create and display a search from the selected event. This feature can also be used to quickly search for replays
	Jumps to the program in the Guide - View 1
	Switch to the File Database Editor

From:
<https://nayal.de/> -

Permanent link:
<https://nayal.de/doku.php/en:sicht4>

Last update: **2024/01/14 19:39**

